

# DEEP FAT FRYER

## INSTRUCTION MANUAL

---



### **LIGHTING INSTRUCTIONS:**

1. Set the thermostat and the gas dial/valve to the OFF position.
2. Wait for 5 minutes.
3. Turn gas dial/valve to PILOT position.
4. Depress the gas dial and apply a lighted match or taper to the pilot.
5. Hold the dial depressed for about 30 sec. or until pilot stays lit before releasing.
6. If the pilot doesn't stay lit, repeat step 4 and 5.

# DEEP FAT FRYER

## INSTRUCTION MANUAL

---

(cont.)

### **BURNERS/THERMOSTAT OPERATION:**

1. After the pilot is lit, turn the gas dial to ON.
2. Turn the thermostat dial to the desire temperature setting and observe the burners ignition. It should ignite within 4 sec.

**CAUTION:** Main burners shall NOT be ON when the vessel is empty. During testing, fill the vessel with (oil/water) until above the heat transfertubes.