

# POPCORN MACHINE

## INSTRUCTION MANUAL



\* Popcorn, oil, or flavoring is not included \*

### INSTRUCTIONS:

#### SAFETY TIPS

- Popcorn machine should be plugged on its own outlet to provide sufficient current
- NEVER force kettle in or out of the brackets to avoid gears to become misaligned
- Ensure the kettle is properly attached to brackets before operating and that the motor plug is plugged into the kettle

# POPCORN MACHINE

## INSTRUCTION MANUAL

---

(cont.)

### INSTRUCTIONS:

#### OPERATING

1. Place machine on a stable, leveled surface.
2. Set up machine near a grounded, electrical source, so that an extension cord is not needed.
3. Gather supplies: Popcorn, seasonings, bowls/bags, cooking oil
4. Plug in the machine with the switch OFF.
5. Turn machine switch ON. Allow machine to run 3-5 minutes to heat up kettle.
6. Turn machine OFF.
7. Add 1 tbsp. of your cooking oil. For best popping results, use vegetable oil.
8. Add popcorn kernels to the kettle. 1 tbsp. oil + 2 oz. popcorn = 8 cups popcorn
9. Turn machine ON and close the door. In no time, you will hear the popping begin. Popcorn will begin to burst out of the flip lids on the kettle.