

# FULL SIZE CONVENTION OVEN

## INSTRUCTION MANUAL



-- Blodgett--

### INSTRUCTIONS:

1. Set the (2)COOL DOWN switch to the COOK position.
2. Turn the (4)THERMOSTAT to the desired operating temperature.
3. Set the (1)HI/LO/OFF switch to the desired position. When the (3)OVEN LIGHT turns off, load the product and set the (5)TIMER.
4. When timer is done, remove the product. If the next product requires a lower temperature, then (2)COOL DOWN switch mode can be used. Leave doors open to help cool down.
5. Turn the oven off by setting the (1)HI/LO/OFF switch to the OFF position.


# FULL SIZE CONVENTION OVEN

## INSTRUCTION MANUAL

(cont.)

### CONTROL DESCRIPTION:

1. **HI/LO/OFF SWITCH** - Controls the operation of the blower. If blower switch is in the OFF position, the oven will be turned off.
2. **COOL DOWN SWITCH** - When switch is on the COOK position, the oven can be used to cook. Cool down position will allow oven to cool down for the next bake.
3. **OVEN LIGHT** - When lit, indicates burners are operating. When light is off, oven has reached operating temperature.
4. **THERMOSTAT** - Controls the temperature at which the oven will operate. Temperatures range 200-500F.
5. **COOK TIMER** - Use to time the length of the cooking operation. When the set time expires, a buzzer will sound.
6. **LIGHT SWITCH** - Operates the oven cavity lights.
7. **HEAT CUTOFF** - circuit breaker.



# FULL SIZE CONVENTION OVEN

## INSTRUCTION MANUAL



-- Royal--

### INSTRUCTIONS:

1. Turn the thermostat dial to the OFF position. Place the power switch to the OFF position.
2. Wait 5 min.
3. Place power switch to the ON position. Turn thermostat to the desired temperature.
4. To turn off, turn the thermostat and power switch to the OFF position.

# FULL SIZE CONVENTION OVEN

## INSTRUCTION MANUAL



-- Imperial--

### INSTRUCTIONS:

#### PRE-HEATING

1. Turn power switch to ON. Motor will turn on, indicating that power to oven is on.
2. Set thermostat to desired temperature. The RED light appears indicating "warming up."
3. Prepare product and place in suitable pans. When the RED light turns off, oven has reached desired preheat temperature.

#### COOKING

1. Load product in oven. Place pans in the center of the racks.
2. Set the timer. Once the preset time lapses, turn TIMER to OFF position to stop alarm.
3. Remove cooked product from oven.

# FULL SIZE CONVENTION OVEN

## INSTRUCTION MANUAL

(cont.)

### **INSTRUCTIONS:**

#### **CLEANING**

1. Turn thermostat to OFF.
2. Turn power switch to COOL DOWN. Leave doors open while fan is on to help cool the oven.
3. When oven has cooled sufficiently, turn power switch to OFF to clean the oven.