

COFFEE MAKER

INSTRUCTION MANUAL



SAFETY PRECAUTIONS:

- Scalding may occur if the lid is removed during the brewing cycle
- Never touch hot surfaces; use handles or knobs
- Close supervision is necessary when this appliance is used near children
- Do not use coffeemaker for any other use than brewing coffee or heating water
- 50-cup coffeemaker - Do not make less than 25 or more than 50 cups of coffee at a time
- 100-cup coffeemaker - Do not make less than 40 or more than 100 cups of coffee at a time

COFFEE MAKER

INSTRUCTION MANUAL

(cont.)

INSTRUCTIONS:

1. Remove cover, basket and stem.
2. Fill the coffeemaker with COLD water to the desired level using the markings on the inside of the coffeemaker. DO NOT use hot water to brew coffee.
3. Wet the coffee basket to avoid small particles from sifting through. No filter is needed.
4. Place stem in the center of the coffeemaker, then place the basket on the stem.
5. Pour the ground coffee evenly into the basket. DO NOT use drip or finely ground coffee as flooding of the basket can occur.
6. Place the cover on and turn clockwise until the tabs lock securely into the handles.
7. Plug in the coffeemaker into a standard household 120 volt AC wall outlet to begin brewing process.
8. The RED indicator light will appear once brewing has finished. The coffeemaker will automatically switch to a "keep warm" setting.
9. Enjoy and serve. For best flavor, remove coffee basket with grounds to avoid bitter oils from dripping into the coffee.
10. Unplug the coffeemaker when 2-3 cups remain.

CLEAN UP:

- Unplug coffeemaker when not in use
- Allow coffeemaker to cool before removing parts
- Rinse the inside and clean out the basket with grounds before returning